


# FIELD INSTALLATION OF POLYETHYLENE WRAP


## STEP 1:

PLACE TUBE OF POLYETHYLENE MATERIAL ON PIPE PRIOR TO LOWERING IT INTO TRENCH.




## STEP 2:

PULL TUBE OVER THE LENGTH OF THE PIPE. TAP TUBE TO END AT JOINT. FOLD MATERIAL AROUND THE ADJACENT SPIGOT END AND WRAP WITH TAPE TO HOLD THE PLASTIC TUBE IN PLACE. INSTALL BONDING STRAP OR WIRE AT EVERY JOINT OF PIPE PRIOR TO WRAPPING AS PER SECTION 4.08c OF THE STANDARD SPECIFICATIONS.



## STEP 3:

OVERLAP FIRST TUBE WITH ADJACENT TUBE AND SECURE WITH PLASTIC ADHESIVE TAPE. THE POLYETHYLENE TUBE MATERIAL COVERING THE PIPE SHALL BE LOOSE. EXCESS MATERIAL SHALL BE NEATLY DRAWN UP AROUND THE PIPE BARREL, FOLDED ON TOP OF PIPE AND TAPED IN PLACE.



CITY OF CRIPPLE CREEK  
WATER DEPARTMENT

POLYETHYLENE WRAP

DESIGNED BY L. OTTO	DATE 12-22-42	DRAWN BY	DATE
APPROVED BY	DATE	CHECKED BY	SCALE NONE
JOB NO.	SHEET NO.		
REV. NO.	REV. DATE		
REV. NO.	REV. DATE		